



BB2-3020, BB2-7020
LonWorks BACnet Gateway
Rev. 1.0 – March 2015

User Guide

Babel Buster 2

© 2015 Control Solutions, Inc.

User Guide Contents

- [1 Introduction](#)
 - 1.1 How to Use This Guide
 - 1.2 Overview of Gateway Devices
 - 1.3 Important Safety Notice
 - 1.4 Warranty
 - 1.5 Required License Information
- [2 Overview of Gateway Functions](#)
 - 2.1 Object Server Model for a Gateway
 - 2.2 Data Flow in the Gateway
 - 2.3 LonWorks Objects and Function Blocks
- [3 Overview of How to Configure Gateway](#)
 - 3.1 Pick Your Approach
 - 3.2 Build Configuration from CSV List of BACnet Objects
 - 3.3 Build Configuration from XIF File (LonWorks Device)
 - 3.4 Build Configuration from Scratch
 - 3.5 Commissioning Gateway as Node on Network
- [4 Tool 'Connect' Page](#)
 - 4.1 Connecting Configuration Tool to Gateway Device
- [5 Tool 'Obj Import' Page](#)
 - 5.1 Importing a CSV Object List
- [6 Tool 'Obj List' Page](#)
 - 6.1 Auto-Building the Configuration
 - 6.2 Editing the Object List
 - 6.3 Object List Export
 - 6.4 Definition of BACnet Object Configuration Parameters
 - 6.5 Definition of BACnet Client Map Configuration Parameters
- [7 Tool 'NV Import' Page](#)
 - 7.1 Importing an XIF File
- [8 Tool 'NV List' Page](#)
 - 8.1 Configuration from Object List
 - 8.2 Configuration from XIF File
 - 8.3 Building Configuration Manually
 - 8.4 Using the NV Editor
- [9 Tool 'Master List' Page](#)
 - 9.1 Editing Configuration from Master List Page
 - 9.2 Sending Configuration To Device
 - 9.3 Getting Configuration From Device
 - 9.4 Fixing Conflicts
- [10 Tool 'View Data' Page](#)
 - 10.1 Viewing Object Data
 - 10.2 Changing Object Data
 - 10.3 Diagnostics - Object Reliability
- [11 Tool 'BACnet Port' Page](#)
 - 11.1 BACnet Device Settings

- 11.2 BACnet Object Counts
- 11.3 MS/TP Port Settings
- 11.4 IP Port Settings

[12 Tool 'LonWorks' Page](#)

- 12.1 Viewing ID Information
- 12.2 Node Location
- 12.3 Node Domains
- 12.4 Changing Program ID

[Appendix A – Diagnostics via USB Console](#)

- A.1 Connecting to Console
- A.2 Commands

[Appendix B – LonWorks Trouble Shooting](#)

- B.1 General Practice, LED Indicators
- B.2 Object Status Bits

[Appendix C – BACnet Trouble Shooting](#)

- C.1 Observing BACnet Errors, LED Indicators

[Appendix D - BACnet CSV Object List Format](#)

- D.1 Data Labels on Header Line
- D.2 Example CSV Files and Imports

[Appendix E - BACnet Codes](#)

- E.1 BACnet Object Property Codes
- E.2 BACnet Engineering Units Codes

[Appendix F – LonWorks XIF File Format](#)

- F.1 XIF Program Interface File

[Appendix G - Configuration XML File Format](#)

- G.1 Configuration Files - Do Not Edit XML

[Appendix H - USB Driver Installation](#)

- H.1 Driver Installation

[Appendix J - Hardware Details](#)

- J.1 Service Button & USB Connection
- J.2 Front Panel LED Indicators
- J.3 Internal Diagnostic LED Indicators
- J.4 RS-485 Line Termination & Bias
- J.5 Server Module Init Jumper