

# Babel Buster SPX Pro V2

## Quick Start Guide

1. Connect power. Apply +12 to +24VDC or 24VAC to the terminal marked "POWER", and common or ground the the terminal marked "GND".
2. Connect a CAT5 cable between the RJ-45 jack and your network switch or hub. You cannot connect directly to your PC unless you use a "crossover" cable.
3. The default IP address as shipped is 10.0.0.101. Open your browser, and enter "http://10.0.0.101/" in the address window. You should see a page with the "Babel Buster" header shown above. From this point, you will find help on each page in the web site contained within the product. You can change the IP address on the System -> Setup -> Network page.
4. The default login is user name "system" with password "admin". You can also log in as "root" using password "buster".
5. Be sure to save any configuration changes you made on the System -> Setup -> Config File page by clicking the Save button. Changes made in the various configuration web pages will be lost upon power cycle or restart if not saved on the Config File page.



NOTE: If the yellow Link LED is not on, check your cable connections. It should be on any time power is applied and an Ethernet connection is present.

The server takes 1-2 minutes to boot up after power is applied. Your browser will not connect until fully booted up.

Ethernet activity LED, normally flashes to indicate network activity (is on solid during boot-up although there is no traffic).

Ethernet Link LED, will always be on if Ethernet is connected (may blink during boot-up)

Communications LEDs:  
 Red: Error in response, or timeout (no response).  
 Yellow: Request sent or received.  
 Green: Good response.

Modbus RTU RS-485 (EIA-485) network.      Power, +12 to +24VDC or 24VAC.      Ground, power common.

